



TaskPro[®]

Maintenance Procedures

An indispensable asset for any maintenance department, TaskPro is a comprehensive database of 250 step-by-step maintenance procedures relating to facility and equipment maintenance.

TaskPro covers all sorts of maintenance procedures, from air compressors and heat pumps to fire doors, cranes, elevators and generators.

TaskPro quickly and easily installs directly into your FaciliWorks database or can be printed as hard copy from the included Word .doc file and every procedure is fully customizable.

Use TaskPro to save time and effort setting up your maintenance procedures and to promote efficient operations and maintenance throughout your facility. Order TaskPro today!



FaciliWorks[®]
Making Maintenance Manageable

1-800-776-3090

www.cybermetrics.com

+1 (480) 295-3465

sales@cybermetrics.com

Index of TaskPro Procedures

A-1 Air Dryer, Refrigerated or Regenerative Desiccant Type
A-2 Unitary, Heating and Cooling Unit
A-3 Humidification Systems
A-4 Air Compressor
A-5 Air Conditioning Machine; Split System
A-6 Air Conditioning Machine Package Unit (Comfort Cooling)
A-7 Air Conditioning Machine, Package Unit (Special Purpose)
A-8 Air Conditioning, Window Unit
A-9 Air Cooled Condenser
A-10 Heat Pumps
A-11 Air Handler Unit
A-12 Glycol Dry Cooler
A-13 Air Conditioning Unit, Ceiling/Wall Mounted
A-14 Air Washer or Wet Coil System
A-15 After-Cooler/Separator
A-24 Ash Conveyor Tube (Pneumatic and Hydraulic)
B-1 Battery Charger
B-2 Boiler (Coal, Oil, and Gas)
B-3 Burners, Gas
B-4 Burner, Oil
B-5 Electric Boilers
B-6 Boiler Instrument/Control
C-1 Clocks, Central System
C-2 Remote Air Intake Dampers
C-3 Coils Preheat, Reheat, Etc. (Remote Locations)
C-4 Central Mini-Computer, HVAC Systems
C-5 Automatic Mixing Box Pneumatic or Electric
C-6 Controls, Central System, Heating and Air Conditioning
C-7 Condensate or Vacuum Pump
C-8 Central Control Panel
C-9 Cooling Tower, Maintenance
C-10 Cooling Tower, Cleaning
C-11 Evaporative Condenser
C-13 Crane, Electric
C-14 Chain Hoist and Trolley
C-16 Cooling Pond
C-21 Carts and Scooters (Engine or Battery Powered)
C-24 Condensing Unit, Refrigeration
D-1 Door, Power Operated
D-2 Dumbwaiter
D-3 Drains, Roof, Gutter (per 100')
D-4 Door, Automatic Hydraulic Electric or Pneumatic Operated Main Entrance

D-5 Doors, Main Entrance
D-6 Drains, Areaway, Storm, Driveway (per Section)
D-7 Sediment Basin
D-9 Distiller, Laboratory Water Only
D-10 Door, Manual Overhead
E-1 Elevators, Electric or Hydraulic
E-2 Elevators, Electric or Hydraulic
E-3 Elevators, Electric or Hydraulic
E-4 Elevators, Electric or Hydraulic
E-15 Escalator
E-16 Escalator
E-17 Expansion Joints In Piping
E-18 Emergency Lights (Wet Cell)
E-19 Emergency Lights (Closed Systems)
E-20 Induction Disc Over Current Relay
E-21 Over and/or Under Voltage Relay
E-22 Thermal Over Current Relay
E-23 Induction Disc – Directional Over Current Relay
E-24 Power Factor Reverse Current, or Watt Type Relay
E-25 Ground Fault Type Transformer or Differential Relay
E-25A Bolted Pressure Contact Switch (low voltage)
E-26 Low Voltage Molded Case Circuit Breaker
E-27 Low Voltage Power Air Circuit Breakers (Over 50 Amps)
E-28 Motor Starters, 100 Horsepower and up
E-29 High Voltage Oil Circuit Breaker
E-30 Switchboards, Medium Voltage (Per Cubicle)
E-30A Switchboard, (Low Voltage) (Per Cubicle)
E-31 Network Protectors
E-32 High Voltage Network and Power Type Transformer (Oil Filled)
E-33 High Voltage Network and Power Dry Type Transformers
E-34 Disconnects (Isolating Switch; Per Switch)
E-34A Disconnect or Isolating Switch (Low Voltage, 200 Amps or More)
E-35 Motor Control Center (Including Motor Starters under 100 hp)
E-36 Automatic Transfer Switch
E-37 Aluminum Bus Duct and Connectors
E-38 High Voltage Air Circuit Breaker
E-39 Supervision Set
E-40 Emergency Generator, Electric, Gasoline or Natural Gas Engines
E-41 Emergency Generator, Electric Diesel Power
E-42 Emergency Generators, Electric
E-43 Lead Acid Battery (Per Cell)
E-44 Edison Nickel-Iron-Alkaline Battery (Per Cell)
E-45 Emergency Generator Steam Turbine Driven

E-45A Emergency Generator Steam Turbine Driven
E-49 Emergency Pumps and Ventilators
E-50 Emergency Pumps and Ventilators
E-51 Motor Starter, 5 HP to less than 100 HP and less than 600 volts
E-52 Auxiliary Protective Relays
E-56 Dimmer and Control Stage and General Lighting
E-57 Low Voltage Dry Type Transformer (30 KVA or More, 600 Volts or Less)
F-1 Alarm Check Valves and Accessories
F-2 Dry Pipe, Deluge and Preaction Valves
F-2a Dry Pipe, Deluge and Preaction Valves
F-2b Dry Pipe, Deluge and Preaction Valves
F-3 Fire Post Indicator Valve
F-4 Fire Control Valves (4" or over) for Interior Water Distribution Systems
F-5 Fire Pumps (Motor or Engine Driven)
F-6 Fire Pumps (Motor or Engine Driven)
F-7 Fire Pumps (Motor or Engine Driven)
F-8 Fire Hose (1.5", Racked in Buildings)
F-9 Fire Department Hose Connections (Standpipe Outlets)
F-11 Fire Doors – Stairwells and Exitways (Swinging)
F-12 Fire Doors – Sliding Type
F-14 Automatic Fire Detection or Alarm Devices
F-15A Fire Alarm Control Panel, Special Systems
F-15B Central Station Transmitter
F-15C Central Station – Receiver and Re-Transmission Equipment
F-16 Fire Alarm System – Recorder
F-17 Fire Alarm Boxes (Manual Coded and Uncoded)
F-18 Fire and Smoke Dampers
F-19 Fire Hydrants (Dry Barrel or Wet Barrel)
F-20 Sprinkler Heads – Sprinklered Areas
F-21 Fire Extinguisher – Soda Acid or Foam
F-22 Fire Extinguisher – Stored Pressure with Gauge
F-22A Fire Extinguisher – Stored Pressure With Gauge (Non-Stainless Steel Shell)
F-23 Fire Extinguisher – Gas Cartridge or Cylinder (No Gauge)
F-24 Fire Extinguisher – Inspection
F-25 Fire Extinguishers, Hydrostatic Testing of Carbon Dioxide, Stored Pressure and Cartridge Type
F-26 Fire Extinguisher Systems – Carbon Dioxide (High Pressure) Halon, Dry Chemical
F-27 Fan, Centrifugal
F-28 Filter, Movable Curtain, Oil Coated
F-29 Filter, Roll Type, Disposable
F-30 Filters, Viscous Type (Wire Mesh)

F-31 Filter, Roll Type Disposable Media, Manual or Motor Driven
F-32 Filter, Throw Away
F-33 Filters, Electrostatic
F-34 Fluorescent Light Fixture Washing and Relamping
F-35 Fluorescent Light Fixture Relamping Only
F-36 Fans, Propeller, 24" Diameter or Larger
F-37 Floor Polishing Machine
F-38 Lightning Protection (Per Down Conductor)
F-39 Cafeteria Exhaust Hood, Per 10 ft of Duct
F-40 Filter, Throw Away, Bag Type
F-43 Filter, Charcoal
F-44 Fountain, Memorial or Decorative
F-46 Fireplace
F-47 Fireplace
F-49 Filter, Control Air
G-1 Fuel Oil Filter/Strainer
G-2 Grease Traps
H-1 Hot Water Converters (Steam)
H-2 Hot Water Heater – Gas
H-3 Hot Water Heater – Electric
H-5 Hot Water Heater – Steam Coil
H-6 Hot Air Furnace
H-12 Unit Heater, Fuel Oil
H-14 Hoist, Lighting
H-15 Hoist, Electric
I-1 Incinerator
I-2 Fan Coil Units, Under Window Type
I-3 Induction Units, Under Window Type
I-4 Fan Coil Unit, Ceiling Hung
I-5 Fan Coil Unit, Ceiling Hung, VAV Box with Electric Reheat
L-1 Lawn Mower and Edger
L-2 Loading Ramp, Adjustable
L-3 Lighting, Special Fixture
L-4 Lighting, Outside;
L-5 Lawn Sprinklers (Per Nozzle)
L-6 Locomotive, Diesel Engine
L-7 Locomotive, Diesel (Electrical)
L-8 Spotlights, Fixed and Portable
L-10 Lift, Electric, Stage Screen
M-1 Manhole, Electrical
M-2 Manholes, Sewer
M-3 Motors
M-6 Material Handling Equipment, Engine Driven
M-7 Material Handling Equipment, Non-Power Operated

M-8 Magnetic Drive
M-10 Motor Controller Unit, 600 Volts or 200 HP and Above
M-11 Motors, 3-Phase, 600 Volts or 200 HP and Above
P-1 Paper Baler
P-2 Pneumatic Tube System
P-4 Pump, Centrifugal
P-6 Pump, Vacuum
P-7 Pump, Gear and Reciprocating
R-1 Radiator, Heating
R-2 Roof Inspection (All Types)
R-3 Refrigeration Machine (Absorption)
R-4 Central Chilled Water Package Unit:
R-5 Refrigeration Machine, Centrifugal
R-6 Refrigeration Machine, Reciprocating and Scroll
R-7 Refrigeration Machine, Rotary Screw
R-8 Control Panel, Central Refrigeration Unit
R-9 Radiation – Baseboards/Convectors (Steam, Hot Water, or Electric, per Linear Foot)
R-10 Railroad Trackage
R-11 Refrigeration Controls, Central System
R-12 Railroad Turnouts
R-14 High Efficiency Purge Units
S-2 Sewage Ejector (Pneumatic Tank Type Ejectors)
S-5 Sweeper
S-6 Sewage Ejector, Sump Type
S-7 Sump Pump
S-8 Strainer, Y-Type
S-9 Strainer, Bolted Flange Type (Water and Steam)
S-10 Scrubbing Machine (Battery or Propane Powered)
S-11 Snow Blower
S-14 Dual Strainer
S-15 Backwash Strainer
T-1 Tanks, Water, (All Types)
T-2 Tank, Air/Refrigerant/LP Gas
T-3 Tanks, Fuel Oil Storage
T-5 Trash Compactor
T-6 Tank, Chemical
T-8 Traps (All Types)
T-9 Turbine, Steam, High Pressure
T-10 Telecommunications
T-12 Transmission, Fluid Drive
U-1 Unit Heaters (Steam and Hot Water)
U-2 Unit Heater (Gas and Oil Fired)
V-1 Vacuum Cleaner, Heavy Duty, Tank Type
V-2 Valve, Safety Relief

V-3 Valves, Regulating
V-5 Valve, Manually Operated
V-6 Valve, Motor Operated
V-7 Valve, Hydraulic/Pneumatic/Electric
V-8 Check Valve, Critical
V-9 Backflow Preventer
V-10 Vacuum System, Centralized
W-1 Drinking Water Filter Systems
W-2 Wash, Emergency
W-3 Water Softener
W-4 Filter, Water
W-5 Window Washing Scaffold, Power Operated
W-7 Wheelchair Lift
W-8 Water Treatment for Cooling Systems
W-9 Water Treatment for Heating Systems
X-21 Key Card System
X-22 Electric Flag Pole
X-23 Unit Heater, Electric
X-26 Solar Heating System
X-26A Solar Heating System, (Solar Collectors)
X-29 Chemical Feeder
X-32 Parking Arm Gates
X-37 Emergency Shower
X-39 Septic Tank
X-41 Tractor, Diesel
X-42 Metal Enclosed Buss Duct (Low Voltage, 600 Vac or Less)

Sample Procedure: A-2 Unitary, Heating and Cooling Unit

Frequency: Annual

Application:

This guide card applies to self-contained heating and cooling units containing a complete cooling system and heating unit (gas or oil burner). These are normally installed on rooftops, but can be in other locations. They are also referred to as climate changers, roof packs, etc.

Special Instructions:

1. Schedule shutdowns with operating personnel, as needed.
2. Review manufacturer's instructions.
3. Review the Standard Operating Procedure for "Controlling Hazardous Energy Sources."
4. De-energize, lock and tag electrical circuits.
5. Comply with the latest provisions of the Clean Air Act and Environmental Protection Agency (EPA) regulations as they apply to protection of stratospheric ozone.
6. No intentional venting of refrigerants is permitted. During the servicing, maintenance, and repair of refrigeration equipment, the refrigerant must be recovered.
7. Whenever refrigerant is added or removed from equipment, record the quantities on the appropriate forms.
8. Recover, recycle, or reclaim the refrigerant as appropriate.
9. If disposal of the equipment item is required, follow regulations concerning removal of refrigerants and disposal.
10. If materials containing refrigerants are discarded, comply with EPA regulations as applicable.
11. Refrigerant oils to be removed for disposal must be analyzed for hazardous waste and handled accordingly.
12. Closely follow all safety procedures described in the Material Safety Data Sheet (MSDS) for the refrigerant and all labels on refrigerant containers.

Check Points:

1. Remove debris from air screen and clean underneath unit.
2. Inspect gaskets. Look for leaks between unit and structure, caulk as necessary.
3. Clean condenser, cooling coil fins, and fans.
4. Remove dirt or dust from all interior parts.
5. Replace filter.
6. Inspect and adjust damper.
7. Lubricate motor and fan bearings.
8. Check fan RPM to design specifications.
9. Check bearing collar set screws on fan shaft to make sure they are tight.

10. Check dampers for dirt accumulations. Check felt. Repair or replace as necessary.
11. Check damper motors and linkage for proper operation.
12. Lubricate mechanical connections of dampers sparingly.
13. Clean coils by brushing, blowing, vacuuming or pressure washing.
14. Check coils for leaking, tightness of fittings:
 - a. Check for refrigerant leaks using a halogen detector or similar testing device. If leaks are not able to be stopped or corrected, report leak status to supervisor. Consult the Material Safety Data Sheets (MSDS) for disposal requirements. Reclaimed and recycled CFCs are exempt from hazardous waste regulations (Consult 40 CFR Part 261).
 - b. Check refrigerant levels and recharge if needed.
15. Use fin comb to straighten coil fins.
16. Flush and clean condensate pans and drains.
17. Check belts for wear, adjust tension or alignment and replace belts when necessary. Multi-belt drives should be replaced with matched sets.
18. Check rigid couplings for alignment on direct drives and for tightness of assembly. Check flexible couplings for alignment and wear.
19. Check electrical connections for tightness.
20. Check mounting for tightness.
21. Check for corrosion.
22. Check mounting bolts and tighten if needed.
23. Check and adjust, or replace if necessary, vibration eliminators.
24. Compressor.
 - a. Check compressor oil level.
 - b. Run machine, check action of controls, relays, switches, etc., to see that:
 - (1). Compressor(s) run at proper settings.
 - (2). Reheat coils activate properly.
 - (3). Crankcase heater is operating properly.
 - (4). Suction and discharge pressures are proper.
 - (5). Discharge air temperature is set properly.
25. Heating Unit.
 - a. Gas and/or oil fired (if equipped).
 - (1). Check burner for flashback and tight shutoff of fuel.
 - (2). Check operation of controls. Clean and adjust if necessary.
 - (3). Clean burner, chamber, thermocouple and control. (Use a high suction vacuum and/or brush.) Check combustion chamber for cracks, holes, or other defects.
 - (4). Adjust pilot or electric ignition device.

- (5). Inspect vent and damper operation.
 - (6). Operate unit and adjust burner.
 - (7). Check operation of safety pilot, gas shutoff valve, and other burner safety devices.
 - (8). Check temperature differential and controls.
 - (9). Check frame of unit with ohmmeter for proper electric ground.
 - (10). Replace covers (if any) and clean area.
- b. Electrical (if equipped).
- (1). Visually inspect for broken parts, contact arcing or any evidence of overheating. Inspect all wiring for deterioration.
 - (2). Check name plate for current rating and controller manufacturer's recommended heater size. (Heater size shall not be changed without the regional design engineer's approval.)
 - (3). Check line and load connections and heater mounting screws for tightness.

Tools and Materials:

1. Tool Group A
2. Tachometer
3. Grease gun and oiler
4. Pressure washer
5. Vacuum
6. Fin comb
7. Cleaning tools, approved refrigerant, and materials. Consult the MSDS for hazardous ingredients and proper personal protective equipment.
8. Safety goggles and gloves.
9. CO2 analyzer
10. Self sealing quick disconnect refrigerant hose fittings
11. Refrigerant recovery/recycle unit
12. EPA/DOT approved refrigerant storage tanks.